

Repair Manual



LK36-LK40-LK45



LK50-LK55-LK60

INDEX

1.	INTRODUCTION	Page 3
2.	REPAIR INSTRUCTIONS	Page 3
	2.1 Repair of the Mechanical Part	Page 3
	2.1.1 Dismantling the Mechanical Parts	Page 4
	2.1.2 Assembling the Mechanical Parts	Page 15
	2.1.3 Classes of Increase	Page 31
	2.2 Repair of the Hydraulic Parts	Page 31
	2.2.1 Head Disassembly - Valve Units	Page 31
	2.2.2 Head Assembly - Valve Units	Page 35
	2.2.3 Disassembling the Plunger Unit - Supports - Seals	Page 41
	2.2.4 Assembly of the Plunger Unit - Supports - Seals	Page 44
	2.2.5 Manifold Bushings	Page 47
3.	SCREW CALIBRATION	Page 48
4.	REPAIR TOOLS	Page 49
5.	SPECIAL VERSIONS	Page 49
6.	REPLACING CON-ROD BUSHING	Page 50
7.	MAINTENANCE LOG	Page 51

1. INTRODUCTION


This manual contains the instructions for repairing LK Series pumps, and must be carefully read and understood before performing any repair intervention on the pump. Correct use and adequate maintenance is fundamental for the pump's regular operation and long wear. General Pump declines any responsibility for damage caused by the misuse or the non-observance of the instructions described in this manual.

2. REPAIR INSTRUCTIONS



2.1 Repair of the Mechanical Parts

Repairs on the mechanical parts must be carried out after removing the oil from the crankcase. To remove the oil, remove the oil fill plug, (pos. 1, fig. 1) and then the drain plug, (pos. 2, fig.1) present on both side of the crankcase.



Exhausted oil must be collected in an appropriate container and disposed of in an authorized location. Do not under any circumstances discard into the environment.

2.1.1 Dismantling the Mechanical Parts

The correct sequence is the following:

Completely drain the oil of oil, as indicated in 2.1.


Remove the valve lifters from the head and the head from the pump casing as shown in 2.2.1 (from fig. 103 to fig. 105).

Detach the upper inspection cover and the lower inspection cover by unscrewing the 4 attachment screws, as shown in point 2.2.3 (fig. 129 and fig. 140). Slip off the O-rings and replace them if necessary.



Remove the three plungers and the liner/gasket support assemblies, as shown in 2.2.3 (fig. 138, fig. 141 and fig. 142).

Remove the three spray guard spacer rings and the spray guards, as shown in 2.2.3 (fig. 143 and fig. 144)



Unscrew the M6 locking grub screws from the three oil seal covers (pos.1, fig.2).




Screw in a threaded bar or an extractor M6 screw in the holes in the oil seal covers (pos. 1, fig.3) and remove the covers from the pump assembly (pos. 1, fig. 4).




Take out the radial seal ring, (pos. 1, fig. 5) and the outside O-ring (pos.1, fig 6).




Remove the lug from the PTO shaft (pos. 1, fig. 7)





Unscrew the attachment screws from the shaft end cover (pos. 1, fig. 8) and slip the cover off the PTO shaft.




Unscrew the crankcase cover attachment screws (pos. 1, fig. 9) and remove it. Slip off the O-ring and replace it if necessary.





Now remove the two bearing covers by unscrewing the screws (pos. 1, fig.10). To help with their removal, use 2 M8 grub screws or screws (pos. 1, fig 11) as extractors. Slip off the O-ring and replace if necessary.





Insert a shim under the shank of the central connecting rod, to stop the rotation of the crankshaft (pos. 1, fig. 12).



Unscrew and take out the bushing locking flange attachment screws, from both sides (pos. 1, fig. 13). The bushing locking flanges must be left in position (pos. 1, fig. 14).




On one side, screw a ferrule (type SKF KM20) onto the pressure bushing (pos. 1, fig. 15), and then unblock the bushing using a striking hammer (pos. 1, fig 16), but do not remove it. Repeat the operation on the other side.



Remove the shim from under the shank of the central connecting rod.

Unscrew the connecting rod screws (pos.1, fig. 17).




Dismantle the small ends of the connecting rods with the half-bearings. During the operation take particular care to note the order in which the parts are removed




The connecting rod small ends and the big end halves must be reassembled in exactly the same order and pairings in which they were dismantled.


To prevent any errors, small ends and big end halves are numbered on one side (pos. 1, fig. 18).




Advance the three big end halves as far as possible in the direction of the head. Slip off the three upper half-bearings of the beg end halves (pos. 1, fig 19).




Take out both of the pressure bushings (pos. 1, fig. 20).





Separate the bushing locking flange from the pressure bushing (pos. 1, fig. 21).




Unscrew the screws of the two bearing support covers (pos. 1, fig. 22).





Apply an M16 threaded pin to one end of the crankshaft (pos. 1, fig. 23) and, while keeping it raised, take out the bearing support cover complete with bearing and O-ring (pos. 1, fig. 24). To help with their removal, use 2 M10 grub screws or screws (pos. 2, fig. 23) as extractors. Repeat the operation on the other side





Lay the crankshaft on the bottom of the crankcase. Separate the bearing support cover from the bearing, using a striking hammer (pos. 1, fig. 25).





Unscrew the attachment screws of the left and right PTO bearing cover (pos. 1, fig. 26) and slip the two covers off the PTO shaft. To help with their removal, use 3 M8 grub screws or screws (pos. 1, fig. 27) as extractors.




Take out the radial seal ring (pos. 1, fig. 28) and the outside O-ring (pos. 1, fig. 29) and the lubrication hole O-ring (pos. 1, fig. 30)



Roll back the three connecting rods as far as possible (until they touch the crankshaft). Using a striking hammer or mallet (pos. 1, fig. 31), take out the PTO crankshaft from either one of the two sides (pos. 1, fig. 32).







Slip the internal bearing rings off the PTO shaft (pos. 1, fig. 33) and also slip off the two internal bearing spacers (pos. 2, fig. 33).




The internal and external bearing rings must be reassembled in exactly the same order and pairings in which they were dismantled.


Using a sufficiently long bar (pos. 1, fig. 34) and a striking hammer, take the bearing rings out of the pump casing (pos. 1, fig. 35), along with the external spacer (pos. 1, fig. 36) and the bearing lubrication bushing (pos. 1, fig. 37).





Advance the big end halves in the direction of the hydraulic part and lock them in place using the special tool (p/n F27566200) (pos. 1, fig. 38).




Move the crankshaft from the lower part of the casing (pos. 1, fig. 39).




Proceed to unscrew the screws of the device (p/n) F2756620) to unlock the connecting rods (pos. 1, fig. 40) and then take out the connecting rod/piston head assemblies from the rear opening of the casing (pos. 1, fig. 41).





Couple the big end halves to the small ends that were previously dismantled, with reference to their numbering scheme (pos. 1, fig. 42).



Remove the two pin-locking Seeger rings using the correct tool (pos. 1, fig. 43).



Slip out the pin (pos. 1, fig 44) and take out the connecting rod (pos. 1, fig. 45).



To separate the stem from the piston head, it is necessary to unscrew the hexagonal-head M10 screw using a no. 17 socket wrench (pos. 1, fig. 46).




Complete the disassembly of the mechanical parts by removing the oil level lights and the eyebolts.

2.1.2 Assembling the Mechanical Parts

Proceed with the assembly, following the reverse of the procedure shown in 2.2.1/ The correct sequence is as follows:


Attach the two oil level lights and the two oil drain plugs (pos. 1 and 2, fig. 47).



Connect the stem to the piston head. Insert the piston guide rod into its seat on the piston guide (pos. 1, Fig. 48) and join the rod to the piston rod using the 4 M6x20 screws (pos. 1, fig. 49).



Place the stem in a vice, closing the teeth of the vice on the two flat areas, and proceed with setting, using a torque wrench (pos. 1, fig. 50) as shown in section 3, "Screw tightening settings".



Insert the connecting rod into the piston head (pos. 1, fig. 45) and then insert the pin (pos. 1, fig. 44). Apply the two shoulder Seeger rings using the correct tool (pos. 1, fig. 43).



The assembly is correct if the small end, piston head and pin rotate freely.

Separate the small ends from the big end halves. Correct pairing is ensured by the numbering on one side (pos. 1, fig. 42). After verifying that the casing is perfectly clean, insert the big end half/piston head assembly into the cylinder tube in the casing (pos. 1, fig. 41).




The big end half/piston head assembly must be inserted into the housing with the numbering of the big end halves visible from above.

Lock the three assemblies using the special device (p/n F27566200) (pos. 1, fig. 40). Lock the crankshaft through the rear opening of the casing and lay it on the bottom.




The crankcase must be inserted into the casing so that the teeth on the ring bevel gears are oriented as shown in fig. 51.





Pre-assemble the PTO shaft:

Onto the PTO shaft, slip on the 2 internal rings of the bearings (one per side) (pos. 1, fig. 52).



The internal and external bearing rings must be reassembled in exactly the same order and pairings in which they were dismantled.

From one side of the casing, insert the bearing lubrication bushing (pos. 1, fig. 53) and an external bearing ring (pos. 1, fig. 54) using a pad and a mallet or striking hammer.




Remove the device for locking the connecting rods (p/n F27566200) (pos. 1, fig 40) and roll back the connecting rods until they touch the crankshaft.

Insert the pre-assembled PTO shaft into the casing (pos. 1, fig. 55). Insert it from the other side to the side where the external bearing ring and the bearing lubrication bushing were inserted.




The PTO shaft must be inserted into the casing so that the teeth are oriented as shown in fig. 55.



It is easier to insert the PTO shaft completely inside the bearing by applying an M16 screw to the end of the shaft being inserted, to keep the shaft lifted up (pos. 1, fig. 56).



From the side of the casing where the PTO shaft was inserted, proceed to insert the bearing lubrication bushing (pos. 1, fig. 57) and an external bearing ring (pos. 1, fig. 58) using a pad and a mallet or striking hammer.



At both sides, insert the internal bearing spacers (pos. 1, fig. 59) and the external bearing spacers (pos. 1, fig. 60).



Insert the internal ring (pos. 1, fig. 61) and external ring (pos. 1, fig. 62) of a bearing from one side of the pump only.





Pre-assemble the left and right PTO covers:



Insert the radial seal ring into the PTO bearing cover using the correct tool (F27539500) (pos. 1, fig. 63). Before proceeding with the assembly of the radial seal ring, verify the condition of the seal lip. If it is necessary to replace it, position the new ring as shown in fig. 64.



If the PTO shaft shows diametral wear corresponding to the seal lip, then to avoid grinding you can position the ring as a second step as shown in fig. 64.





Apply the external O-ring (pos. 1, fig. 65) and the lubrication hole O-ring (pos. 1, fig. 66) to the PTO bearing covers.



Mount one of the PTO bearing covers (left or right) on the pump casing (pos. 1, fig. 67) and attach it with four M8X30 screws (pos. 1, fig. 68).



Be careful of the direction of assembly of cover. The lubrication hole in the cover must correspond to the hole in the casing.



Repeat the operations on the other side:


Insert the internal ring (pos. 1, fig. 61) and external ring (pos. 1, fig. 62) of the second bearing.


Mount the second PTO bearing on the pump casing (pos. 1, fig. 67) and attach it with 4 M8X30 screws (pos. 1, fig. 68).

Tighten the 4 screws with a torque wrench, as shown in section 3, "Screw Tightening Settings".

Pre-assemble the two bearing covers:


Insert the bearing using a mallet or striking hammer (pos. 1, fig. 69) until 4 to 4.5 mm of the bearing is still protruding, as shown in fig. 70







The bearing in fig. 70 has a conical internal ring. Verify that the conicity is from the outside to the inside to allow the subsequent insertion of the bushing.

Apply the O-ring to the outside of the bearing support cover (pos. 1, fig. 71).




Repeat the operation with the other cover. Lock the three connecting rod assemblies, using the special tool (F27566200) (pos. 1, fig. 40).

Apply two M16 threaded pins to the end of the crankshaft and, while keeping it raised (pos. 1, fig. 72), insert the bearing support cover complete with bearing and O-ring (pos. 1, fig. 73) using a mallet or striking hammer. Repeat the operation on the other side.





Fasten the bearing support covers with 6 M10X30 screws (pos. 1, fig. 74). Tighten the screws with a torque wrench, as shown in section 3. "Screw Tightening Settings".



Partly insert the two pressure bushings, keeping the crankshaft lifted up by means of the previously mounted M16 pin (pos. 1, fig. 75).



Insert the pressure bushing completely onto the crankshaft (pos. 1, fig. 76 and fig. 77) using a mallet or striking hammer and a pad.







The pressure bushing must be inserted dry (no lubricant).

Insert the bushing until the outside (conical) surface perfectly couples with the inside of the bearing. During insertion, make sure that the bearing stays in contact with the crankshaft shoulder.

Repeat the operation on the other side.

Insert the bushing locking flanges into the conical bushings (pos. 1, fig. 78). Apply a sufficiently long (30-40 mm) M16 screw to the M16 hole on the crankshaft and screw it in, until the flange is touching the bushing (pos. 1, fig. 79). **DO NOT TIGHTEN THE SCREW.**




Repeat the operation on the other side.

Remove the tool for locking the connecting rods (F27566200) (pos. 1, fig. 40).

Insert the upper half-bearings between the connecting rods and the crankshaft (pos. 1, fig. 80)



To correctly assemble the half-bearings, make sure that the lug on the half-bearing is positioned in the slot on the big end half (pos. 1, fig. 81).





Apply the lower half-bearings to the small ends (pos. 1, fig. 82), making sure that the lugs on the half-bearings are positioned in the slots on the small ends (pos. 1, fig. 82)

Attach the small ends to the big end halves using the M12X1.25X87 screws (pos. 1, fig. 83). Tighten the screws with a torque wrench, as shown in Section 3, "Screw Tightening Settings", bringing the screws to the tightening torque at the same time.




When the operation is finished, check that the connecting rods have axial clearance in both directions.




When the operation is finished, check that the connecting rods have axial clearance in both directions.


Insert a shim under the shank of the central connecting rod, to stop the rotation of the crankshaft (pos. 1, fig. 84).



Measure the distance X indicated in fig. 85 between the conical bushing and the crankshaft bearing.



Screw in the M16 screw until there is a reduction in the distance X of between 0.7 mm and 0.8 mm (fig. 86).





Repeat the operation on the other side.

Remove the M16 screw from the crankshaft. Screw the two bushing locking flanges onto the crankshaft using 4 M12X25 screws (pos. 1, fig. 87).





Apply **LOCTITE 243** to the threads of the **M12X25** screws (pos. 1, fig. 87).

Tighten the screws with a torque wrench, as shown in section 3, "Screw Tightening Settings".





Remove the anti-rotation shim from under the shank of the central connecting rod.


Mount the two bearing covers (with their O-rings) (pos. 1, fig. 89) using 6 M8X20 screws (pos. 1, fig. 90). Tighten the screws with a torque wrench, as shown in section 3, "Screw Tightening Settings".




Insert the O-ring into the rear cover (pos. 1, fig. 91) and affix it to the casing using 10 M8X20 screws (pos. 1, fig. 92). Tighten the screws with a torque wrench, as shown in section 3 "Screw Tightening Settings".





Mount the radial seal ring onto the oil seal cover (pos. 1, fig. 93) using a pad (F27910900).



Position the O-ring (pos. 1, fig. 94) on the seat of the oil seal cover.





Insert the assembly into the casing and into the seat provided, making sure that the cover completely enters its seat (pos. 1, fig. 95), being careful not to damage the lip of the radial seal ring. Screw in the oil seal covers using 2 M6X30 grub screws (pos. 1, fig. 96).





Tighten the screws with a torque wrench as shown in section 3, "Screw Tightening Settings".

Position the spray guard and the spray guard spacer ring in the seat on the piston head stem (pos. 1, fig. 97 and fig. 98).




Insert O-rings on the two inspection covers (pos. 1, fig. 99) and mount the covers using 4 M6X14 screws (pos. 1, fig. 100).




Tighten the screws with a torque wrench, as shown in section 3, "Screw Tightening Settings".

Mount the shaft end cover and affix it to the casing using 3 M8X20 screws (pos. 1, fig. 101). Tighten the screws with a torque wrench, as shown in section 3 "Screw Tightening Settings".



Apply the lug to the PTO shaft (pos. 1, fig. 102).



2.1.3 Classes of Increase

INCREASE TABLE FOR CRANKSHAFT AND CONNECTION ROD HALF-BEARINGS			
Recovery Classes (mm)	Upper half bushing p/n	Lower half bushing p/n	Crank pin grinding measures (mm)
0.25	90931100	90930100	Ø 92.75 0/-0.03 Roughness Ra 0.4 Rt 3.5
0.50	90931200	90930200	Ø 92.50 0/-0.03 Roughness Ra 0.4 Rt 3.5


INCREASE TABLE FOR PUMP CASING AND PISTON HEAD		
Recovery Classes (mm)	Piston Head p/n	Crank pin grinding measures (mm)
1.00	74050243	Ø 81 H6 + 0.22/0 Roughness Ra 0.8 Rt 6

2.2 Repair of the Hydraulic Parts



2.2.1 Dismantling the head - the valve assemblies

The head requires preventive maintenance as indicated in the Owner's Manual. Operations are limited to inspection or replacement of the valves, when necessary. To extract the valve assemblies work as follows:



Unscrew the valve lifter using a 30 mm spanner (pos. 1, fig. 103).




Apply two supports with G2" threading to the outlet connections of the head (pos. 1, fig. 104) and then unscrew the 8 M16X150 screws (pos. 1, fig. 105). Take care to not subject the plungers to knocks or bumps when taking them out of the head.




Unscrew and remove the 8 M16X55 screws of the valve cover (pos. 1, fig. 106) and remove the cover (pos. 1, fig. 107).




Remove the valve plug by using a slide hammer puller applied to the M10 hole in the valve plug (pos.1, fig. 108).



Slide out the spring (pos. 1, fig. 109).




Remove the outlet valve assembly by using a slide hammer puller applied to the M10 hole in the valve holder (pos. 1, fig. 110).




If it is particularly difficult to remove the outlet valve assembly (e.g. there are build up deposits because the pump has not been used for a long period), use the extractor tool F27516400 (for LK36,40,45) or p/n F27516500 (for LK50, 55, 60).


Take out the valve holder spacer, using an 8mm hexagonal key (pos. 1, fig. 111).




Remove the inlet valve assembly by using a slide hammer puller applied to the M10 hole in the valve holder (pos. 1, fig. 112).



If it is particularly difficult to remove the outlet valve assembly (e.g. there are build up deposits because the pump has not been used for a long period), use the extractor tool F27516200 (for LK36,40,45) or p/n 27516300 (for LK50, 55, 60) (pos. 1, figs 113) and use it as shown in the diagram.



Remove the inlet and outlet valve assemblies by screwing in an M10 screw so as to attach it to the inside holder and take out the valve holder from the valve seat (pos. 1, fig. 114).




2.2.2 Assembling the Head - The Valve Assemblies



Check the state of wear of the various components very carefully and replace them if necessary. At each inspection of the valves, replace all the O-rings, both for the valve assemblies and for the valve plugs.



Before repositioning the valve assemblies, clean their seats in the head, located by the arrows (pos. 1, fig. 115), and then dry these seats completely.



Proceed with the assembly, following the reverse of the disassembly procedure shown in 2.2.1.

Assemble the inlet and outlet valve assemblies (fig. 116 and fig. 117), taking care not to reverse the springs that were previously removed.

To facilitate insertion of the valve holder into the seat, place a pipe on the horizontal flat surface of the holder (fig. 118) and use a mallet/striking hammer around the entire circumference.







Proceed with the insertion of the valve assemblies (inlet and outlet) into the head, taking care to follow the correct insertion sequence of the O-rings and the anti-extrusion rings.

The correct assembly sequence for the valve assemblies in the head is as follows:



Insert the anti-extrusion ring, exploded Position #4, from Owner's Manual, (pos. 4, fig. 119).




Insert the O-ring, exploded position #5, from Owner's Manual, (pos. 1, fig. 120).





Make sure the O-ring and anti-extrusion ring are perfectly seated in place. Insert the inlet valve assembly (pos. 1, fig 121). The complete valve assembly must be inserted all the way in, as shown in pos. 1, fig. 122.




Mount the O-ring, exploded position #5, from Owner's Manual, (pos. 1, fig. 123) and the anti-extrusion ring, exploded position #15 (pos. 2, fig. 123), onto the outlet valve seat.




Insert the outlet valve assembly (pos. 1, fig. 124). The valve assembly must be inserted all the way in, as shown in pos. 1, fig. 125.




Insert the anti-extrusion ring, exploded position #16 (pos. 1, fig. 126).





Insert the O-ring, exploded position #17 (pos. 1, fig. 127)




Be very careful when inserting the O-ring indicated in pos. 1, fig. 128. We recommend using the special tool, p/n F27516000 (for LK36, 40, 45) or p/n F27516100 (for LK50, 55, 60), to prevent the O-ring from being cut during insertion.





Insert the valve seat ring (pos. 1, fig. 129) and the spring (pos. 1, fig. 130).





Mount the O-ring, exploded position #17 (pos. 1, fig. 131) and the anti-extrusion ring, exploded position #21 (pos. 2, fig 131), onto the outlet valve plug.



Insert the valve plug, complete with O-ring and anti-extrusion ring. After insertion of the valve assemblies and the valve plugs is complete, replace the valve cover (pos. 1, fig. 132) and screw in the 8 M16X55 screws (pos. 1, fig. 133).



Attach the head to the pump casing (pos. 1, fig. 134) taking care not to subject the plungers to knocks or bumps, and screw in the 8 M16X150 screws (pos. 1, fig. 135).





Proceed to tighten the M16X150 screws with a torque wrench, as shown in section 3 “Screw Tightening Settings”.



Tighten the 8 M16X150 screws, beginning by cross-tightening the 4 inside screws (see fig. 135) and then moving on to the 4 outside screws, again, cross-tightening them.

Tighten the M16X55 screws of the cover with a torque wrench, as shown in section 3, “Screw Tightening Settings”.

Insert the valve lifters (pos. 1, fig. 136) and screw them in using a 30 mm spanner (pos. 1, fig. 137).



2.2.3 Dismantling the Plungers-Supports-Seals Assembly


The plunger assembly requires regular inspection as indicated in the preventive maintenance table in the Owner's Manual. Operations are limited to a visual check for any draining from the hole in the lower cover. If there are anomalies/oscillations in the outlet pressure gauge, or drips from the drain hole, then the seal packing must be checked and, if necessary, replaced. To extract the plunger assemblies, work as follows:

To access the plunger assembly, unscrew the M16X150 screws and dismantle the head.





Take the greatest care when sliding out the head to avoid subjecting the plungers to knocks or bumps.


Remove the plungers by unscrewing the attachment screws (pos. 1, fig. 138). Slide the plunger from the gasket support and check that its surface does not have scratches, signs of wear or cavitation.




Remove the upper inspection cover (pos. 1, fig. 139) and the lower inspection cover (pos. 1, fig. 140) by unscrewing the 4 attachment screws.



Manually rotate the shaft to bring the 3 plungers into the top dead center position. Insert the plastic buffer (p/n F27516600) between the plunger head and the plunger (pos. 1, fig. 141).





By rotating the shaft, advance the plunger head so that the plastic buffer advances in its turn and expels the gasket support and the entire plunger assembly (pos. 1, fig. 142).





Remove the gasket support assembly and the plastic buffer.


Slip the spray guard spacer rings off the plunger heads (pos. 1, fig. 143) and also the spray guards (pos. 1, fig. 144).




Separate the gasket support from the liner by using a compass spanner with $\varnothing 5$ round ends, available on the market, (pos. 1, fig. 145) and unscrew the support until it is completely removed (pos. 1, fig. 146).



Manually remove the head rings, the pressure gaskets and the restop rings (pos. 1, fig. 147).



To remove the low pressure gasket, use a feeler gauge or other tool that does not damage the gasket support seat (pos. 1, fig. 148).



2.2.4 Assembling the Plungers - Supports - Seals Assembly

Proceed with the reassembly, following the reverse of the disassembly procedure shown in 2.2.3.




Replace the pressure gaskets, moistening the lips with silicone grease (without covering the gaskets), and taking great care not to damage them while inserting them into the liner.





At every disassembly, the pressure gaskets must always be replaced, together with all the O-rings.


Insert the low pressure gasket into the gasket support (pos. 1, fig. 149), taking care to follow the direction of assembly: the seal lip goes in front (towards the head).




Insert the head ring (pos. 1, fig. 150), the high pressure gasket (pos. 1, fig. 151) and the restop ring (pos. 1, fig. 152).




Place the O-ring for the gasket support on its seat (pos. 1, fig. 153).





Screw the gasket support to the liner (pos. 1, fig. 154) and tighten using a compass spanner with $\varnothing 5$ round ends, available on the market (pos. 1, fig. 155), until the support abuts the liner.



Place the 14x2 O-ring on its seat on the plunger attachment screw (pos. 1, fig. 156).




Place the plungers on their respective holders (pos. 1, fig. 157) and fix them in place as in pos. 1, fig. 158.




Tighten the screws with a torque wrench, as shown in section 3, "Screw Tightening Settings".



Insert the previously assembled liner/gasket support block (complete with its two O-rings, until it is snugly in place (pos. 1, fig. 159).



Make sure that the liner/support block goes all the way in and is correctly positioned on its seat (pos. 1, fig. 160).



Place the frontal O-ring on the liner (pos. 1, fig. 161) and also the O-ring for the recirculation hole (pos. 1, fig. 162).



The manifold bushing must be assembled by driving bushes (pos.1) together with the anti-extrusion rings (pos. 2) and O-rings (pos. 3) and shown in fig. 167 for LK36-40-45 and fig. 168 for LK50-55-60.




Fig. 167




Fig. 168

- No. 1 - Bush LK36-40-45 - Part # 78216756 - Qty. 3
- No. 2 - Anti-extruding Ring - Part # 90526880 - Qty. 6
- No. 3 - O-ring - Part # 90410200 - Qty. 6

- No. 1 - Bush LK50-55-60 - Part # 78216656 - Qty. 3
- No. 2 - Anti-extruding Ring - Part # 90528500 - Qty. 6
- No. 3 - O-ring - Part # 90412900 - Qty. 6

3. SCREW CALIBRATION

Screws are to be fastened exclusively using a torque wrench.

Description	Exploded View Position (From Owner's Manual)	Fastening Ft. Lbs.	Fastening Nm
M8x20 screw, casing cover	54	18.44	25
G1/2x13 plug, casing	78	29.5	40
M8x30 screw, PTO bearing cover	95	18.44	25
M8x20 screw, shaft end cover	54	18.44	25
M10x30 screw, bearing support cover	69	33.2	45
M6x14 screw, upper & lower covers	82	7.38	10
M8x20 screw, bearing cover	54	18.44	25
M12x1.25x87 screw, connecting rod tightening	52	55.32	75*
M6x14 screw, plunger head	49	7.38	10
M12x25 screw, bushing locking flange	63	50.52	68.5
M10x160 screw, plunger attachment	27	29.5	40
M16x55 screw, valve cover	26	245.6	333
G1/4"x13 screw, head	13	29.5	40
M16x150 screw, head	25	245.6	333**
Valve lifter	2	29.5	40

* Reach the tightening torque by tightening the screws simultaneously.

** Tightening sequence always cross-wise starting from the 4 internal screws (see fig. 135) then the 4 external screws.

4. REPAIR TOOLS

Pump maintenance may be carried out using simple tools for assembling and disassembling components. The following tools are available:

For Assembly:

- Plunger head radial seal ring p/n F27910900
- PTO shaft radial seal ring p/n F27539500
- p/n F27548200
- O-ring, outlet valve seat (LK36, LK40, LK45) p/n F27516000
- O-ring, outlet valve seat (LK50, LK55, LK60) p/n F27516100

For Disassembly:

- Inlet valve seat (LK36, LK40, LK45) p/n F27516200
- Inlet valve seat (LK50, LK55, LK60) p/n F27516300
- Outlet valve seat (LK36, LK40, LK45) p/n F27516400
- Outlet valve seat (LK50, LK55, LK60) p/n F27516500
- Liner + gasket support block p/n F27516600
- Shaft (for locking connecting rods) p/n F27566200

5. Special Versions

The instructions for repairing special versions are given below. Unless specified otherwise, refer to the information in this repair manual for standard LK pump

- LKN pumps: for repair, follow the instructions for the standard LK pumps.

6. Replacing the connecting rod bushing

Perform cold-driving of the bushing and the subsequent work bearing in mind the dimensions and tolerances shown in fig. 169 below.




Fig. 169

MAINTENANCE LOG

HOURS & DATE

OIL CHANGE							
GREASE							
PACKING REPLACEMENT							
PLUNGER REPLACEMENT							
VALVE REPLACEMENT							



GP Companies, Inc.
1174 Northland Drive
Mendota Heights, MN 55120
Phone: 651.686.2199 Fax: 800.535.1745
www.generalpump.com email: sales@gpcompanies.com

Ref 300772 Rev.B
03-20