- Specifically designed for the agricultural market
- · Solid ceramic plungers
- · Optimized inlet and outlet valves
- · Dual lip oil seal
- · Dual shaft configurations
- · Smooth shaft available
- Cast iron manifold with aluminum valve covers
- "HR" high resistance anti-corrosion treatment on manifold



### **SPECIFICATIONS**

Pump Model	AB90DP	AB100DP	AB120DP	AB180DP	
Maximum Volume	23.8 GPM	26.4 GPM	31.7 GPM	47.6 GPM	
Maximum Discharge Pressure	870 PSI				
Horsepower	14.0 HP	15.6 HP	18.7 HP	28.1 HP	
Maximum Pump Speed	650 RPM	550 RPM	550 RPM	650 RPM	
Maximum Inlet Pressure	45 PSI				
Plunger Bore	1.42 in. / 36 mm	1.57 / 40 mm	1.78 in. / 45 mm	1.97 in. / 50 mm	
Plunger Stroke	1.78 in. / 45 mm				
Oil Capacity	77.8 oz.				
Inlet Port Thread	1-1/2" BSPP				
Discharge Port Thread	1" BSPP				
Shaft Diameter	1.375 ASAE - DUAL				
Weight	90.4 lbs.				
Dimensions	17.48" x 17" x 8.29"				







## Instructions and Recommendations for the Installation of

# AB Series Pumps


In order to obtain maximum performance in terms of duration of seals and valves, it is necessary to respect a few simple rules, as follows:

1) In order to avoid damage caused by cavitation, the pump must be pressure fed.

The higher the inlet pressure, the longer the life of the wet end of the pump.

When working at 185°F (85°C), the minimum feed pressure - measured directly in the inlet port of the pump when it is working - is 45 psi (3 bar).

The minimum feed pressure according to the different temperatures are:



Naturally, if the application allows for feeding the pump with 45 psi (3 bar) even at low temperatures (for example: 115°F/45°C the life of the wet end of the pump will be even longer.

- 2) The plumbing which feeds the pump must be of a diameter at least equal to the inlet port. Also, follow the suggestions below:
  - a) Make the plumbing as short and straight as possible, preferably in an upward direction to facilitate the expulsion of eventual air bubbles naturally if compatible with the requirements of the system.
  - b) It is always useful to put a filter at the inlet with capacity of 4 to 5 times the flow of

the pump, for example for a 4 gpm (15 l/min) pump, put a filter from 16 to 20 gpm (60-75 l/mi)The mesh size suitable for this application is 0.016" (.4 mm).

c) It is extremely important to put a pressure switch on the suction port of the pump, and in any case downstream from the filter, so that it can stop the pump should the feed pressure drop by 20% due to the filter clogging or failure of the feed pump, etc.

#### 3) Change of oil

We recommend the *first oil change after the first 50 hours*, with the *pump stopped* and the *oil still warm*.

This change is not recommended because the oil has lost its properties, but rather to eliminate the impurities that have gotten into the oil during the running-in phase. If these impurities are not removed, but are allowed to remain in the oil, they may cause premature wear to the moving parts and the oil seals. After this initial change, the oil can then be changed every three months or 300 hours of operation thereafter.

Please note: If the pump works in conditions with high humidity and with sharp temperature changes, it is possible that condensation will appear inside the crankcase, which mixing with the oil can change its properties. This is easy to see because the oil changes to a white, milky color.


If the pump does not have excessive water leaking from the packings, and the oil becomes milky, the oil has to be changed more frequently. The percentage of water in the oil must not exceed 20%.

#### Use oil per the following chart:

CHART OF COMPATIBLE OILS SAE15W40				
General Pump	Series 100			
BP	VISCO 2000			
CASTROL	CWX			
MOBIL	SUPER			
SHELL	HELIX SUPER			
TOTAL	QUARTZ 4000-5000			

Ref 300927 Rev.D 04-19

# AB Series Triplex Plunger Pump



Р			
	Λ		

No	Part No.	Description	Qty.
1	68010022	Crankcase	1
2	68160022	Rear Cover	1
3	98204250	Plug, G1/4" x 12	1
4	90358500	O-ring, Ø10.82x1.78	1
5	90395000	O-ring, Ø215.57x2.62	1
6	99185400	Screw, M6x16	22
8	91947800	Key	1 or 2
9	90069500	Snap Ring	1 or 2
10	68210554	Spacer, Bearing	1 or 2
11	91847300	Roller Bearing	2
12	90167200	Oil Seal, 35x52x7	1 or 2
13	70150022	Side Cover	1 or 2
14	70150122	Side Cover, PTO	1
15	90391500	O-ring, Ø80.6x2.62	2
16	70220081	Shim, 0.1 mm	
10	70220381	Shim, 0.25 mm	
17	90075600	Restop Ring	1
18	70211801	Oil Sight Glass	1
19	90387700	O-ring, Ø39.34x2.62	1
20	98211500	Oil Dipstick	1
21	96709900	Washer, Ø10x45x1	3
22	98050022	Plunger Guide	3
23	90167600	Ring, Rad. Ø36.34x2.62	3 3 3
24	97742500	Pin, Ø18x45	3
25	68030001	Connecting Rod Assy.	3
26	99309900	Connecting Rod Screw	3
27	68210651	Protector	1
28	68210782	Sponge, Guaranty	
30	68020335	Crankshaft, PTO, 1-3/8"	1
31	68020235	Crankshaft, PTO	1
32	68020435	Crankshaft, PTO, 1-3/8"	1

No	Part No.	Description	Qty.
33	68210851	Protective Cover	1
	68120013	Manifold, Ø36	1
34 68120113 68120213		Manifold, Ø40	1
		Manifold, Ø45	1
	68203133		
35	99446600	Screw, M12x130	8
	68080070	Packing Retainer, Ø36	3
36	68080171	Packing Retainer, Ø40	3
30	68080270	Packing Retainer, Ø45	3 3 3 3 3 3
	68080370	Packing Retainer, Ø50	3
	90279800	Packing, Ø36, LP	3
37	90282800	Packing, Ø40, LP	3
31	90284600	Packing, Ø45, LP	3
	90286000	Packing, Ø50, LP	3
38	90390000	O-ring, Ø58.42x2.62	3
30	90390700 O-ring, Ø63.17x2.62		3 3 3
	68210070	Intermediate Ring, Ø36	3
20	68210170	Intermediate Ring, Ø40	3
39 68210270		Intermediate Ring, Ø45	3
	68210370 Intermediate Ring, Ø50		3
	90283800	Restop Ring, Ø40x55x8/4.5	3
40	90286500	Restop Ring, Ø50x65x8/4.5	3
40	90281800	Restop Ring, Ø36x45x6/3	3
	90284800	Restop Ring, Ø45x60x6.3/3	3
	90282000	Packing, Ø36x48x6/3.5, HP	3
41	90283200	Packing, Ø40x55x6/3.5, HP	3
41	90286300	Packing, Ø50x65x7.5/4.5, HP	3 3 3 3 3 3 3
90285000		Packing, Ø45x60x7.5, HP	
	71100251	Head Ring, Ø36	3 3 3
42	71100351	Head Ring, Ø40	3
42	76100251	Head Ring, Ø45	3
68100051		Head Ring, Ø50	3

No	Part No.	Description	Qty.
43	90389300	O-ring, Ø53.65x2.62	6
44	68210422	Valve Cover	2
45	99430500	Screw, M12x40	16
	71040409	Plunger, 36x95 (AB90DP)	3
46	71040509	Plunger, 40x95 (AB100DP)	3
40	68040009	Plunger, 45x99 (AB120DP)	3
	68040109	Plunger, 50x95 (AB180DP)	3
47	71219566	Plunger Screw	3
48	90367100	O-ring, Ø11x2	3
49	36720601	Valve, Outlet	3
50	36200951	Valve Cage	3
51	94745000	Spring, 16x27.5	3
52	36201076	Valve Plate	3
53	36204866	Valve Seat	3
54	90386500	O-ring, Ø29.82x2.62	3
55	90517800	Anti-ext Ring	3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
56	36720501	Inlet Valve Assembly	3
57	36204551	Inlet Valve Guide	3
58	94754100	Spring, Ø24.7x31	3
59	36211576	Valve Plate	3
60	36211666	Inlet Valve Seat	3
61	90388000	O-ring, Ø42.52x2.62	3
62	90523300	Anti-ext. Ring	3
63	98244100	Cao, G1-1/2"x20	1
64	96802000	Washer, Ø48x60x1.5	1
65	98232500	Cap, G1"x17	1
66	96787000	Washer, Ø33.5x38x1.5	1
67	76200074	Pump Foot	2
68	99426600	Screw, M12x25	4
69	96719500	Washer, Ø13x18x1.1	

### AB Series **Triplex Plunger Pump**

#### TOROUE SPECS\* REPAIR KITS


Kit No.	K295	K296	K297	K298	Ø36 (AB90)	Ø45 (AB120)	Ø50 (AB180)
					K299	K301	K302
ltem Nos. Included In Kit	43, 50, 51, 52, 53, 54, 55 (49)	43, 57, 58, 59, 60, 61, 62 (56)	23	12	37, 38, 40, 41, 42	37, 38, 40, 41, 42	37, 38, 40, 41, 42
Number of Assy's In Kit	3	3	3	2	3	3	3
Number of Cylinders Kit Services	-	-	3	NA	3	3	3

TURQUE SPECS"							
Position	FtLbs.	Nm.					
3	14.8	20					
6	7.4	10					
26	14.8	20					
35	59	80					
45	59	80					
47	14.8	20					
63	110.6	150					
65	88.5	120					
68	59	80					

\*Decrease torque by 20% if threads are lubricated.

\*\*Use Loctite 542 Red

#### **DIMENSIONS**



A suitably-calibrated over pressure valve must be installed, as well as the pressure regulating valve, must be installed on the high-pressure line.

The high-pressure pipes must be correctly sized for the system's maximum working pressure and used exclusively withing the working pressure range indicated by the pipe manufacture and marked on the pipe itself.



The ends of the high-pressure pipes must be sheathed and secured to a solid structure, so as ti avoid the risk of whiplash if the connections burst or break.

The pump transmission systems (joints, pulleys, belts, rotary shafts), must be suitably covered by a protective case.

If in doubt, do not hesitate to call the Interpump Group / General Pump Customer Service.

